




Locate the 7 digit serial # from one of the three locations list below.



1. QR Code Label on the CVT



2. CVT Case or Label



3. Valve Body

